

Goose Creek

Lat: 61°26'38.97"N Long: 149°52'49.48"W

Lat: 61°26'39.02"N Long: 149°52'10.54"W

Lat: 61°26'32.33"N Long: 149°52'49.18"W

Lat: 61°26'32.37"N Long: 149°52'36.24"W

Lat: 61°26'26.21"N Long: 149°52'36.02"W

Lat: 61°26'26.18"N Long: 149°52'10.23"W

















