



Lat: 61°37'48.20"N Long: 150°30'30.94"W

Lat: 61°37'48.49"N Long: 150°30'9.72"W

Fish Creek

Lat: 61°37'44.76"N Long: 150°30'6.20"W

Lat: 61°37'43.74"N Long: 150°30'29.84"W















